



D9MS5-DA000

CAR MULTIMEDIA SYSTEM

USER'S MANUAL

DA5
(영어 | 호주) 디오디오2

SPORTAGE



The Power to Surprise

Thank you for purchasing this multimedia system.

This user's manual explains how to use the Kia multimedia system.

Before using the product, read the contents of this user's manual carefully and use this product safely.

- The screens shown in this manual may differ from the actual ones.
- The design and specification of this product may change without prior notification, for product improvement.
- When transferring the vehicle to another individual, include this user's manual so that the next driver can continue its use.

Precautions for safe usage

- Driving while distracted can result in a loss of vehicle control, that may lead to an accident, severe personal injury, or death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.
- Do not operate the multimedia system while driving.
- Do not disassemble, assemble, or modify the multimedia system.
- Do not watch the screen for prolonged periods of time while driving.
- Set the volume to a level which allows the driver to be aware of external conditions.

- Do not operate the multimedia system for prolonged periods of time with the vehicle ignition in ACC. Such operations may lead to battery discharge.
- Be cautious not to spill water or introduce foreign objects into the device.
- Do not cause severe shock to the device. Direct pressure onto the front of the monitor may cause damage to the LCD or touch panel.
- In case of product malfunction, be sure to contact the purchased site or service centre.
- When cleaning the touch screen, make sure to turn off the device and use a dry and smooth cloth. Never use tough materials, chemical cloths, or solvents (alcohol, ammonia, benzene, thinners, etc.) as such materials may damage the device panel or cause colour and quality deterioration.

WARNING

- Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury, or death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

Read the following safety precautions for your safety

Before using the product, read the contents of this user's manual carefully and use this product safely.

※ The design and specifications of this product may change without prior notification, for product and service improvement.

The actual appearance in the vehicle may differ from the illustrations.

For more accurate information about the vehicle, please refer to the catalogue.

※ This multimedia system contains open source software, including without limitation, software distributed and/or modified under the GNU General Public license, Version 2, June 1991, and the GNU lesser General Public License, Version 2.1, February 1999.

For additional information and to obtain related materials including without limitation, the previous referred to licenses and software, please contact us at MOBIS_OSSrequest@mobis.co.kr

Notations used within this User's Manual

WARNING

- Failure to observe the instructions within this category could result in death or serious injury or damage to the vehicle.
-

CAUTION

- Information on matters that could potentially lead to injury, vehicle damage, or malfunction.
-

Information

- Information and tips that provide additional user convenience while using the product.
-

NOTICE

- Information on specific features that facilitate proper product use and functional understanding.
 - Information on terminology used within this manual.
-

Table of Contents

1. Introduction

Warnings and Cautions	1-2
Component Names and Functions	1-4
Multimedia System	1-4
Steering Wheel Control.....	1-6
Starting the System for the First Time	1-8
Turning the System On/Off	1-8
System Reset.....	1-8
Battery Warning Message	1-9
Restrictions on Features for Safety Measures	1-9
Home Screen	1-10
My Menu	1-11
On-Screen Touch Controls	1-11

2. Radio/Media

FM, AM (with RDS)	2-2
USB.....	2-4
Before Playing a USB MP3	2-4
Supported USB MP3 music specifications	2-6
USB Music	2-7
iPod	2-10
Using iPod Devices	2-10
iPod	2-14
Bluetooth Audio.....	2-17
Bluetooth connections	2-18

3. Bluetooth

Before Using the Bluetooth Handsfree.....	3-2
What is <i>Bluetooth</i> ® Wireless Technology?	3-2
Precautions for Safe Driving	3-2
CAUTIONS upon Connecting Bluetooth Phone	3-2
Bluetooth Connection.....	3-4
Pairing a New Device	3-4
Connecting Bluetooth Devices.....	3-4
Disconnecting Bluetooth Devices	3-5
Deleting Bluetooth Devices	3-5
Bluetooth Phone	3-6
Phone Status Icons	3-6
Call History	3-7
Favourites	3-8
Contacts	3-9
Dial	3-10
Accept/Reject Call	3-10
Using the Menu During a Phone Call	3-11

4. Other Features

Climate.....	4-2
Basic Mode Screen	4-2
Camera.....	4-4
Steering-linked camera.....	4-5
Using Voice memo	4-6

5. Settings

Sound settings	5-2
Display settings.....	5-3
Bluetooth settings.....	5-4
Bluetooth connection.....	5-4
Auto connection priority	5-5
System Bluetooth info	5-5
Phone projection settings.....	5-6
Home screen settings	5-6
Date/Time settings	5-6
Language settings	5-7
Keyboard settings.....	5-7
Screen saver settings	5-7
Advanced settings	5-8
System info	5-8
System Update	5-8

6. Appendix

Product Specification.....	6-2
Troubleshooting.....	6-3
FAQ	6-6
About Pairing Mobile Phones	6-6
About Making/Answering Phone Calls	6-7
About <i>Bluetooth</i> [®] Wireless Technology/Multimedia system Use Environment	6-7

iPod®

iPod® is a registered trademark of Apple Inc.

***Bluetooth®* Wireless Technology**

The *Bluetooth®* word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license. Other trademarks and trade names are those of their respective owners.

A *Bluetooth®* Wireless Technology enabled mobile phone is required to use *Bluetooth®* Wireless Technology.



part. 1 Introduction

Warnings and Cautions

Component Names and Functions

Starting the System for the First Time

Introduction

Safety Warnings

- Do not stare at the screen while driving. Staring at the screen for prolonged periods of time could lead to traffic accidents.
- Do not disassemble, assemble, or modify the Multimedia system. Such acts could result in accidents, fire, or electric shock.
- Heed caution not to spill water or introduce foreign objects into the device. Such acts could lead to smoke, fire, or product malfunction.
- If you use phone related functions while driving, you will find it difficult to concentrate on operating the vehicle and the current traffic conditions, so the possibility of an accident may increase. Please use phone related functions only when parked.
- Please refrain from use if the screen is blank or no sound can be heard as these signs may indicate product malfunction. Continued use in such conditions could lead to accidents (fires, electric shock) or product malfunctions.
- Do not touch the antenna during thunder or lightning as such acts may lead to lightning induced electric shock.
- Do not stop or park in parking-restricted areas to operate the product. Such acts could lead to traffic accidents.
- Some functions cannot be used while driving. These functions operate only when the vehicle is parked.

Cautions





Pay attention to traffic conditions while driving.


- Operating the device while driving could lead to accidents due to a lack of attention to external surroundings. First park the vehicle before operating the device. In addition, the touch screen may not work for some functions when the vehicle is in motion. The touch screen feature will be supported once the vehicle has stopped.
- Adjust the volume to levels that allow the driver to hear sounds from outside of the vehicle. Driving in a state where external sounds cannot be heard may lead to accidents.
- Pay attention to the volume setting when turning the device on. A sudden output of extreme volume upon turning the device on could lead to hearing impairment (adjust the volume to a suitable levels before turning off the device).
- Turn on the vehicle ignition before using this device. Do not operate the Multimedia system for long periods of time with the ignition turned off as such operations may lead to battery discharge.
- When you use the Multimedia system for more than 10 minutes with the vehicle engine turned off, a warning appear. After 10 minutes, the warning will appear for 5 seconds every 1 minute.
- Do not subject the device to severe shock or impact. Direct pressure onto the front of the monitor may cause damage to the LCD or touch screen.
- When cleaning the device, make sure to turn off the device and use a dry and smooth cloth. Never use tough materials, chemical cloths, or solvents (alcohol, benzene, thinners, etc.) as such materials may damage the device panel or cause colour/quality deterioration. When experiencing product concerns, inquire with your place of purchase or service maintenance centre.
- Prevent caustic solutions such as perfume and cosmetic oil from contacting the device panel because they may cause damage or discolouration.
- If air freshener liquid gets onto the multimedia system or plastics, it could cause cracks due to chemical reactions. Pay attention when using air freshener. Care must be taken not to allow air freshener liquid to be attached to the air vent. The liquid may enter the vent.

Component Names and Functions

Multimedia System



Name	Description
1  POWER/ VOL	<ul style="list-style-type: none"> When power is off, press to turn power on. When power is on, press and hold for over 0.8 seconds to turn the power off. When power is on, press for less than 0.8 seconds to turn Audio off. Turn left/right to adjust the volume.
2  RADIO	Moves to FM/AM mode. <ul style="list-style-type: none"> Each time the key is pressed, the mode is changed in the following order: FM → AM → FM.
3  MEDIA	Moves to MEDIA mode. <ul style="list-style-type: none"> If the media is not connected, MEDIA mode will not be activated.
4  ☆	Displays the function set by the user.

Name	Description
5  ∨ SEEK TRACK ∨	When the key is pressed for less than 0.8 seconds: <ul style="list-style-type: none"> FM/AM mode: plays the previous/next frequency. MEDIA mode: changes the track, file or title. When the key is pressed and held for more than 0.8 seconds: <ul style="list-style-type: none"> FM/AM mode: moves quickly through all of the frequencies. The moment that you release the button, the system seeks the next available frequency. MEDIA mode: rewinds or fast forwards the track or file (except for Bluetooth Audio).



Name	Description
6 HOME	Moves to the Home Screen.
7 PHONE	Moves to the Bluetooth phone mode.
8 SETUP	Moves to the Setup screen.
9 TUNE	<ul style="list-style-type: none"> FM/AM mode: changes the frequency. MEDIA mode: changes the track, file or title (except for Bluetooth Audio).
10 RESET	Resets the system settings (preset radio channels and other data will not be deleted).



※ The actual appearance in the vehicle may differ from the illustration.

Steering Wheel Control



	Name	Description
1		For more details, refer to Phone Projection guide.
2	MODE	<ul style="list-style-type: none"> Each time this key is pressed, the mode is changed in the following order: FM → AM → USB or iPod → Bluetooth Audio → FM Select the mode to use in Advanced settings. If the media is not connected, the corresponding modes will be disabled. Press and hold the key (more than 0.8 seconds) to turn the multimedia system on/off. When power is off, press the key to turn power back on.
3		Use to adjust the volume of the audio or a call.
		<ul style="list-style-type: none"> Mutes the audio. (It will be paused in some media modes.) Mutes the microphone during a call.
4		<p>When keys are pressed for less than 0.8 seconds:</p> <ul style="list-style-type: none"> FM/AM mode: searches broadcast frequencies saved to Presets. MEDIA mode: changes the track, file or title. <p>When keys are pressed and held for more than 0.8 seconds:</p> <ul style="list-style-type: none"> FM/AM mode: automatically searches broadcast frequencies. MEDIA mode: quickly looks up songs (except for Bluetooth audio files).




Name	Description
<p data-bbox="831 333 850 353">5</p> 	<p data-bbox="991 161 1374 181">When pressed for less than 0.8 seconds:</p> <ul data-bbox="991 188 1481 318" style="list-style-type: none"> • When pressed in the dial screen, makes a call. • When pressed in the incoming call screen, answers the call. • When pressed during call waiting, switches to waiting call (Call Waiting). <p data-bbox="991 322 1469 342">When pressed and held for more than 0.8 seconds:</p> <ul data-bbox="991 349 1481 528" style="list-style-type: none"> • When pressed in Bluetooth Hands-free, redials the last dialed call. • When pressed during a Bluetooth Hands-free call, switches call back to mobile phone (Private). • When pressed while calling on the mobile phone, switches call back to Bluetooth Hands-free (operates only when Bluetooth Hands-free is connected).
<p data-bbox="831 573 850 593">6</p> 	<ul data-bbox="991 546 1481 618" style="list-style-type: none"> • When pressed during a call, ends the phone call. • When pressed in the incoming call screen, rejects the call.

※ The actual appearance in the vehicle may differ from the illustration.

Starting the System for the First Time

Turning the System On/Off

Press the engine start button or set the ignition key to On or ACC. Each time you turn on the system, a boot logo and safety warning will appear.



Pressing the power key on the Multimedia system will display the safety guide.

NOTICE

- It is not possible to operate the system while it is booting up.

Pressing and holding the power key on the Multimedia system will turn off the system.


Information

- If you turn off the system during a phone call using the Hands-free feature, then the call will automatically switch to your mobile phone.

NOTICE

- Check the volume when turning on the system. Before turning on the system, adjust the volume to a reasonable level.

System Reset



The System Reset function restores the system when it is not operating correctly. Press and hold the RESET key for a second or longer (it is recommended that you press the RESET key using a tool, such as a pin or a paperclip).

Battery Warning Message

Always use the system while the vehicle engine is running. If you turn on the system while the engine is off, a battery warning message will appear. When the engine starts, the message will disappear.



NOTICE


- If you use the system for a long time with the engine off, the battery may become completely discharged.
-


Restrictions on Features for Safety Measures

Several features are limited while driving. The restriction screen will disappear when shifting gears into P or applying the parking brake.

Home Screen

Controls Menu Configuration for the Home Screen

Tap the  icon on any screen to display the Home Screen below.













Features	Description
1 Radio/ Media Widget	<ul style="list-style-type: none">Shows brief information on the radio or media that is now playing.Tap the area to move to the mode that you are listening to.
2 Phone projection Widget	Shows any connected devices such as iPod and Bluetooth.
3 All menus	Shows all of the items in the system menu.
4 My Menu	Add your favourite menus to have quick and easy access to them.
5 Apps/Info	Moves to the Apps/Info screen.
6 Settings	Moves to the Settings screen.

Information Display on the Status Bar

Displays the date and time, along with the system status shown by the various icons to the right of the clock.


The icons in the following table indicate the various types of system status details and events.

Icon	Description
	Displayed when the audio is muted.
	Displays the remaining battery of the Bluetooth phone.
	Displayed when connected to Bluetooth for hands-free.
	Displayed when connected to Bluetooth for streaming audio.
	Displayed when connected to Bluetooth for streaming audio and hands-free.
	Displayed when downloading contacts or recent calls from the Bluetooth phone.
	Displayed while on a call using the Bluetooth phone.
	Displayed when the microphone of the Bluetooth phone is muted.
	Displays the signal strength of the Bluetooth phone.
	Voice memo recording.

My Menu

Adding a Feature to My Menu

Select **My Menu** on the Home Screen to add the most frequently used menus, change the menu order, or delete menus.



i Information

- Up to 24 menus can be added to My Menu.

On-Screen Touch Controls

Learn how to touch the screen to operate the system.

Select


Tap lightly on a menu or an item to select it.

NOTICE

- The system will not recognise your touch if you wear a glove or other non-conductive material. Touch the screen using your finger, an electrostatic touch-screen glove, or a stylus pen.
-


Drag & Drop

Select a menu or item you want, then drag and drop it to where you want to place it.



Drag or touch the slider along the play bar in the music screens to jump to the point that you want to play from.

Flick (Quick Scrolling)






Moves quickly up and down in the list.

NOTICE

- Moving the list when there are many items will display a handler on the right of the display. You can easily move many items at a time with the handler.

Select and Hold

Selecting and holding  or  in the music player will rewind or fast forward the music.



part.2 Radio/Media

FM, AM (with RDS)

USB


iPod

Bluetooth Audio

Radio/Media

FM, AM (with RDS)

You can access the radio player either by pressing **RADIO** key or by selecting the Radio menu from **All menus** on the Home Screen.



Features	Description
1 Mode Display	<ul style="list-style-type: none">• Displays currently operating mode.• Tap the desired mode to change to it in Radio.
2 Frequency	Displays the current frequency.
3 Favourites	Show the stored Favourites for user selection.
4 List	Takes you to the FM station list.
5 Scan	Plays the broadcasts for a short time for the frequencies with superior reception for 5 seconds per item.
6 Menu	Sound settings : moves to the sound settings.



Features	Description
7 SEEK/TRACK	<ul style="list-style-type: none"> • If button is pressed for less than 0.8 seconds: seeks the previous/next frequency. • If button is pressed for more than 0.8 seconds: moves quickly through all of the frequencies. The moment that you release the button, the system seeks the next available frequency.
8 TUNE	Turn the TUNE knob to manually seek available frequencies.

USB

Before Playing a USB MP3

Connect the USB device after turning on the engine. The USB device may become damaged if it is already connected when the ignition is turned on.

- Files that are not standard format music files will not be played.
- For MP3/WMA/OGG files, only music files with compression rates between 8 kbps to 320 kbps can be played.
- Heed caution to static electricity when connecting/disconnecting external USB devices.
- Encoded MP3 Players will not be recognised when connected as an external device.
- When connecting an external USB device, the device may not properly recognised the USB is in some instances.
- Only products formatted with byte/sectors under 64 kbytes will be recognised.
- USB devices, formatted to the FAT12, FAT16, or FAT32 file system are recommended. File systems other than FAT12, FAT16, FAT32, exFAT, and NTFS are not supported.
- Some USB devices may not be supported due to compatibility issues.
- Take caution so that the USB connector does not come in contact with body parts or objects.
- Repeated connecting/disconnecting of USB devices within short periods of time may result in product malfunction.
- Make sure to connect/disconnect external USB devices with the audio power turned off.
- The amount of time required to recognised the external USB device may differ depending on the type, size, or file formats stored on the USB.
- The use of USB devices for purposes other than playing music files is prohibited.
- Do not use the USB I/F to charge batteries or USB accessories that generate heat. Such acts may lead to worsened performance or damage to the device.
- The device may not recognised the USB device if separately purchased USB hubs and extension cables are being used. Connect the USB directly with the multimedia terminal of the vehicle.
- When using mass storage USB devices with separate logical drives, only files saved to the root drive can be played.
- When application programs are installed to specific USBs, files may not play properly.

- The device may not operate normally if MP3 Players, mobile phones, digital cameras, or other electronic devices (USB devices not recognised as portable disk drives) are connected with the device.
- Charging through the USB may not work for some mobile devices.
- The device may not support normal operation when using a USB memory type besides Metal Cover Type USB Memory.
- The device may not support normal operation when using formats such as HDD Type, CF, or SD Memory.
- Upon playing iPods, please use a dedicated iPod vehicle cable.
- Normal operations cannot be guaranteed when other cables are being used.
- The device will not support files locked by DRM (Digital Rights Management).
- USB memory sticks used by connecting an Adaptor (SD Type or CF Type) may not be properly recognised.
- Only use Plug type connector products, as shown in the figure below.
- To play USB MP3, the USB device must be connected to the USB port in the front multibox. The USB port in the centre console storage (if equipped) is for charging only.



Plug Type Connector

Product Name	Manufacturer
XTICK	LG
BMK	BMK Technology
SKY-DRV	Sky Digital
TRANSCEND JetFlash	Transcend
Sandisk Cruzer	SanDisk
Micro ZyRUS	ZyRUS
NEXTIK	Digiworks

i Information

- Problems that occur through use of USB devices not listed within the above table are not covered by the product warranty.


Supported USB MP3 music specifications

Name	Description
Audio File Specification	MPEG-1/2 layer3, OGG (Vorbis), FLAC, WMA (Standard/Professional)
Recommended Bit Rates and Sampling Frequency	MPEG-1/2 layer3 <ul style="list-style-type: none">• 8 kbps to 320 kbps (CBR or VBR), to 48 kHz• ID3 Tag: Supports ID3v1.0 and ID3v1.1, ID3v2.3, ID3v2.4 ID3 tags
	OGG (Vorbis): From Q1 to Q10, to 48 kHz
	FLAC: 8 bit/16 bit/24 bit, to 48 kHz
	WMA <ul style="list-style-type: none">• Standard (0x161): to support L3 Profile: to 385 kbps, to 48 kHz• Professional (0x162): to support M0b: to 192 kbps, to 48 kHz
Detailed Specifications	Maximum directory layers: 20 layers Maximum length of folder name/file name: 255 bytes Supported characters for folder name/file name: Alphanumeric characters, Korean standard character set 2,350 characters, Simplified Chinese 4888 characters Maximum number of folders which can be stored onto one USB: 2000 folders (including ROOT) Maximum number of files which can be stored onto one USB: 8000

i Information


- The sound quality of audio files that use bitrates exceeding 192 kbps cannot be guaranteed. When using files without fixed bit rates, some features (FF/REW features) may not operate properly.

USB Music




Features	Description
1 Mode	Displays the current operating mode.
2 Number of files	Number of files on the current playlist.
3 Repeat/Shuffle	From Repeat/Shuffle, displays the current operating function.
4 Play Time	Displays the current play time/total play time.
5 Song Info	Displays the artist/title/album info.

Features	Description
6 Previous File	<ul style="list-style-type: none"> If button is pressed for less than 0.8 seconds: moves to the previous file or plays the current file from the beginning (depends on the play time). - If play time is less than 3 seconds: moves to previous file. - If play time is more than 3 seconds: plays the current file from the beginning. If button is pressed for more than 0.8 seconds: rewinds the track.
7 Play/Pause	Plays/pauses the current file.
8 Next File	<ul style="list-style-type: none"> If button is pressed for less than 0.8 seconds: moves to the next file. If button is pressed for more than 0.8 seconds: fast-forwards the track.
9 Repeat	<p>Repeats the current file.</p> <ul style="list-style-type: none"> If select the file in the file tab on the list screen: select this button to switch between repeating the current file, repeating folder, and repeating all files. If select the song in the other tabs on the list screen: select this button to switch between repeating the current song and repeating all songs.
10 Shuffle	<p>Plays files in random order.</p> <ul style="list-style-type: none"> Select this button to switch between shuffle and turning shuffle off.



Features	Description
11 Delete Current File	A selected file can be deleted. Deleted file can be found in the 'to_delete' folder. <i>i</i> This function is only supported when USB format is compatible with FAT16 or FAT32.
12 List	Moves to the list screen.
13 Menu	<ul style="list-style-type: none"> Delete current file: a selected file can be deleted. Deleted file can be found in the 'to_delete' folder. <i>i</i> This function is only supported when USB format is compatible with FAT16 or FAT32. Sound settings: moves to the sound settings.
14 Back Button	Move to the previous screen.
15 TUNE	<p>Turn the TUNE knob to search a desired track. If the desired track is displayed, press the TUNE knob to play the track.</p> <p><i>i</i> If you do not anything with the TUNE knob for 5 seconds of searching tracks, the track info for the current track is stored.</p>



Features	Description
1 Folder/Category Name	Displays the folder/category name in the list.
2 Current Song	Displays the current playing file name.
3 Back Button	Move to the previous screen.
4 Upper Folder/Category	Moves to upper folder/category.
5 Menu	Show current track: when moving to a different list screen, it displays the list where the current file is located (becomes disabled when the current list includes the current file).
6 Search Menu	Search songs by the list type.
7 SEEK/TRACK	<ul style="list-style-type: none"> If button is pressed for less than 0.8 seconds: plays previous/next track. If button is pressed for more than 0.8 seconds: moves to play screen, and then it will rewind or fast-forward the track.
8 TUNE	Turn the TUNE knob to move the focus to the previous/next list. If the desired track is displayed, press TUNE knob to play the track.

iPod

Using iPod Devices

- iPod is a registered trademark of Apple Inc.
- iPod mode will not operate if the connected iPod cannot be recognised due to operation of unsupported versions that do not support related protocols, iPod abnormalities, or iPod device defects. Some iPods with unsupported communication protocols may not operate properly with the Multimedia system.
- For fifth generation iPod Nano devices, the iPod may not be recognised when the battery level is low. Please charge the iPod for use.
- Search/play orders shown within the iPod device may differ with the orders shown within the Multimedia system.
- If the iPod malfunctions due to an iPod device defect, reset the iPod and try again (to learn more, refer to your iPod manual).
- Repeated connecting and disconnecting of an iPod/iPhone device within short periods of time may result in abnormal operation.
- The time for recognition of an iPod/iPhone may vary depending on device type, firmware version and iOS version.
- For some iPod Touch and iPhone devices, connecting Bluetooth while the iPod is operating may result in discontinued iPod sound. When such devices with Bluetooth support are connected, this problem occurs as the sound source is changed from the Dock Connector (USB connector cable) to Bluetooth.
- Bluetooth Audio function is limited if an iPod/iPhone is connected to the system through both a cable and Bluetooth. To listen to an iPod, use either the iPod menu with a USB connection or Bluetooth Audio with a Bluetooth connection.
- To listen to the iPod sound, reconnect the USB cable or change the audio output settings in iPod/iPhone to Dock.
- In order to use the iPod with the Multimedia system, you must use a dedicated iPod cable (the cable that is supplied when purchasing iPod/iPhone products).

- ※ When the ignition is in ACC, connecting the iPod through the iPod cable (the cable that is supplied when purchasing your iPod) will charge the iPod.
- ※ The use of genuine iPod cables supplied by Apple is recommended. The use of other products may result in noise or abnormal operation.
- ※ To play iPod music through the cable connection, the iPod/USB cable must be connected to the USB port in the front multibox. The USB port in the centre console storage (if equipped) is for charging only.
- When connecting with the iPod cable, make sure to fully insert the jack to prevent communication interference. If the iPod is connected to the vehicle while it is playing, a high pitch tone may sound for about 1 to 2 seconds immediately after connection. If possible, connect the iPod to the vehicle with the iPod stopped/paused.
- Within iPhones, streaming audio and iPod control may occasionally conflict. If problems persist, remove the iPhone and connect again.
- When connecting to iPod Nano/Classic, the Kia logo appears on the Apple device. For the iPod Nano 6 generation, however, the logo image does not appear since it is not supported. Also, all iPhone and iPod Touch products do not support this function.
- In Apple's iOS 6.0 version or later, Podcast and Audiobook media files are designed to be played with the Podcasts and iBooks applications specifically designed for Apple products. If the Apple device does not provide the Podcast and Audiobook lists, the playlist may not be displayed and played in the iPod mode.
- If the Apple Podcasts and iBooks apps are not installed on the Apple device, but the Apple device provides the Podcast and Audiobook lists, you can play files in other categories in iPod mode.
- The screen of the multimedia system may differ when you run other music players (e.g. iHeartRadio) on your connected device.


- While using a connected iPhone/iPod Touch device, it may not operate normally if the user changed some functions in the device.
- When making a call with an iPhone, a song may stop playing due to an Apple device feature. If sound does not resume after the call is terminated, check the device status.
- If lots of songs have the same information, skipping may occur when previous/next song is executed due to an Apple device feature. Also problems may occur depending on device type or iOS version.
- If lots of songs have the same information, there may be a difference when playing songs, between the Multimedia system and the Apple device. Reset the device or delete the same songs in the Apple device using iTunes.
- If you control pause, repeat, shuffle, or seek songs when the play time is less than 3 seconds before play has finished, there may be a difference when playing songs between the Multimedia system and the Apple device. Access iPod music from another mode or pause a song and then play again in the Apple device.
- If the iPhone/iPod Touch supports Bluetooth, and is unable to use Bluetooth Audio when the Apple device is connected to the Multimedia system through the USB connection, disconnect the USB connection, and then use Bluetooth Audio.
- If connected to the Multimedia system while podcast or iTunes music is downloaded to an iPod/iPhone, some problems may occur when you select a song in the list. Reconnect the iPod/iPhone to the Multimedia system when downloading has finished or the file is deleted.
- If connected to the Multimedia system while using sync, some problems may occur. Try to use the iPod/iPhone connection after sync is complete. To learn more, refer to your iPod manual.

- iPhone and iPod Touch devices are guaranteed to work normally on iOS 9.3.2 or below. However, they may not work normally on future iOS versions as their operations have not yet been tested.
- We recommend that your Apple device use the latest firmware because some problems may occur due to outdated firmware or other software related issues.

Type	1G	2G	3G	4G	5G	6G	6.5G	7G	
iPod Mini	Not Supported								
iPod Shuffle									
iPod Nano	○	○	○	○	○	○	Not released	○	
iPod Touch	○ (iOS 1.1 not supported)	○	○	○	○	○	Not released		
iPad	○ (Unable to charge, Not verified, Normal operation not guaranteed)								
iPad Mini									
iPod Classic	Not Supported				○ (iPod with Video)	○ (iPod Classic)	○ (iPod Classic)	Not released	

Type	3G	3GS	4	4S	5	5C	5S	6	6+	6S	6S+	SE	7	7+
iPhone	Not verified, Normal operation not guaranteed	○	○	○	○	○	○	○	○	○	○	○	○	○





iPod




Features	Description
1 Mode	Displays the current operating mode.
2 Number of songs	Number of songs on the current playlist.
3 Repeat/ Shuffle	From Repeat/Shuffle, displays the current operating function.
4 Play Time	Displays the current play time/total play time.
5 Song Info	Displays the artist/title/album info.

Features	Description
6 Previous File	<ul style="list-style-type: none"> If button is pressed for less than 0.8 seconds: moves to the previous file or plays the current file from the beginning (depends on the play time). - If play time is less than 3 seconds: moves to previous file. - If play time is more than 3 seconds: plays the current file from the beginning. If button is pressed for more than 0.8 seconds: rewinds the track.
7 Play/Pause	Plays/pauses the current file.
8 Next File	<ul style="list-style-type: none"> If button is pressed for less than 0.8 seconds: moves to the next file. If button is pressed for more than 0.8 seconds: fast-forwards the track.
9 Repeat	<p>Repeats the current song.</p> <ul style="list-style-type: none"> Select this button to switch between repeating the current song and repeating category all songs. (It all depends on the specification of your Apple device.)
10 Shuffle	<p>Plays songs in random order.</p> <ul style="list-style-type: none"> Select this button to switch between shuffle category and turning shuffle off. (It all depends on the specification of your Apple device.)
11 List	Moves to the list screen.
12 Menu	Sound settings: moves to the sound settings.
13 Back Button	Move to the previous screen.




Features	Description
14 TUNE	<p>Turn the  TUNE knob to search for a desired track. If the desired track is displayed, press the  TUNE knob to play the track.</p> <p> If you do not anything with the  TUNE knob for 5 seconds of searching tracks, the track info for the current track is stored.</p>



Features	Description
1 Category Name	Displays the category name.
2 Category List	Displays the contents of selected category. i If there are many items in the list, items are added in order and the scroll bar on the right is adjusted accordingly.
3 Back Button	Move to the previous screen.
4 Upper Category	Moves to upper category.
5 Search Menu	Search songs by the list type.
6 SEEK/TRACK	<ul style="list-style-type: none"> If button is pressed for less than 0.8 seconds: plays previous/next track. If button is pressed for more than 0.8 seconds: moves to play screen, and then it will rewind or fast-forward the track.
7 TUNE	Turn the TUNE knob to search a desired track. If the desired track is displayed, press the TUNE knob to play the track. If you do not press the knob within 5 seconds, the TUNE knob search will be terminated.

Bluetooth Audio



Features	Description
1 Mode	Displays current operating mode.
2 Phone Name	Displays name of connected phone.
3 Artist Info	Name of current artist.
4 Title	Name of current song.


Features	Description
5 Previous File	<ul style="list-style-type: none"> If play time is less than 3 seconds, moves to the previous file. If play time is over 3 seconds, plays the current file from the beginning. i This function may differ depending on the model of mobile phone.
6 Play/Pause	Plays/Pauses Bluetooth Audio.
7 Next File	Moves to the next file.
8 Repeat	Repeats the current file. i This function may differ depending on the model of mobile phone.
9 Shuffle	Plays files in random order. i This function may differ depending on the model of mobile phone.
10 Menu	<ul style="list-style-type: none"> Connection settings: moves to the Bluetooth Settings. You can pair a new device or change/delete paired device(s). Sound Settings: moves to the sound settings.
11 SEEK/TRACK	Plays the previous/next file.
12 TUNE	T UNE is not supported.

i Information

- Artist info and Title may not be supported by your mobile phone.
- When connecting a mobile phone through a USB cable (while using other functions), Bluetooth audio is disabled.
- Depending on the connected Bluetooth device, mobile phone, or the music player you are using, playback controls may differ.
- Depending on the music player you are using, streaming may not be supported.

Bluetooth connections

Settings for pairing, connection and disconnection of a Bluetooth device.



- In Bluetooth Audio play screen, select **Menu** and then **Connection settings**.

i Information

- If the music in the mobile phone is not played after changing to audio streaming mode, press the play button. Check if the music is playing on the Bluetooth device after changing to audio streaming mode. Audio streaming may not be supported for some mobile phones.
-

part.3 Bluetooth

Before Using the Bluetooth Handsfree

Bluetooth Connection

Bluetooth Phone

Bluetooth

Before Using the Bluetooth Handsfree

What is *Bluetooth*[®] Wireless Technology?

- *Bluetooth*[®] Wireless Technology refers to a short-distance wireless networking technology which uses a 2.45 GHz frequency to connect various devices within a certain distance.
- Supported within PCs, external devices, Bluetooth phones, PDAs, various electronic devices, and automotive environments, *Bluetooth*[®] Wireless Technology can be transmitted at high speeds without having to use a connector cable.
- Bluetooth Handsfree refers to a device which allows the user to conveniently make phone calls with Bluetooth mobile phones through the Multimedia system.
- The Bluetooth Handsfree feature may not be supported in some mobile phones.

Precautions for Safe Driving

- Bluetooth is a feature that enables drivers to practice safe driving. Connecting the Multimedia system with a Bluetooth phone allows the user to conveniently make calls, receive calls, and manage the phonebook. Before using *Bluetooth*[®] Wireless Technology, carefully read the contents of this user's manual.
- Excessive use or operations while driving may lead to negligent driving practices and be the cause of accidents. Do not operate the device excessively while driving.
- Viewing the screen for prolonged periods of time is dangerous and may lead to accidents. When driving, view the screen only for short periods of time.

CAUTIONS upon Connecting Bluetooth Phone

- Before connecting the Multimedia system with the mobile phone, check to see that the mobile phone supports Bluetooth features.
- Even if the phone supports *Bluetooth*[®] Wireless Technology, the phone will not be found during device searches if the phone has been set to hidden state or the Bluetooth power is turned off. Disable the hidden state or turn on the Bluetooth power prior to searching/connecting with the Multimedia system.
- If Auto Connection is used, the Bluetooth phone is automatically connected when the ignition is turned on, making it unnecessary to have to connect the phone with the Multimedia system every time.

- If you do not want automatic connection with your Bluetooth device, turn the Bluetooth feature off on the Bluetooth device.
- Park the vehicle when connecting the Multimedia system with your mobile phone.
- Bluetooth connection may become intermittently disconnected in some mobile phones. Follow these steps to try again.
 1. Turn the Bluetooth function within the mobile phone OFF/ON and try again.
 2. Turn the mobile phone power OFF/ON and try again.
 3. Completely remove the mobile phone battery, and reboot again.
 4. Reboot the Multimedia System and try again.
 5. Delete all paired devices from both the Phone and Multimedia system, then try again.
- The Handsfree call volume and quality may differ depending on the mobile phone.
- Pairing Bluetooth devices and use of other Bluetooth features are not supported when the vehicle is in motion. For safety, please first park your vehicle.
- If you continue having issues with downloading contacts, please check the mobile phone status or inquire with the mobile phone manufacturer.

Bluetooth Connection

Pairing a New Device

Before you can use the Bluetooth feature, you must first pair/connect your mobile phone to your vehicle.

Up to 5 Bluetooth devices can be paired. Only one Bluetooth device can be connected at a time.

Pairing a New Device by Selecting Phone/Call

Press **PHONE** key or **[Phone Icon]** key on the steering wheel control. ▶ Pair your vehicle after your mobile phone detects the Bluetooth device. ▶ Enter the passkey or accept the authorisation popup. ▶ Connect Bluetooth.

Pairing a New Device Through the Phone Settings

Press **SETUP** key ▶ Select **Bluetooth** ▶ **Bluetooth connections** ▶ **Add new** . ▶ Pair your vehicle after your mobile phone detects the Bluetooth device. ▶ Enter the passkey or accept the authorisation popup. ▶ Connect Bluetooth.




The default passkey is 0000.
The vehicle name above is an example.
Check the actual information on the product.

Connecting Bluetooth Devices

Connects the Bluetooth devices that you add.


Connecting Devices by Selecting Phone/Call

Press **PHONE** key or **[Phone Icon]** key on the steering wheel control. ▶ Select the name of the device to connect. ▶ Connect Bluetooth.



Connecting Devices Through the Phone Settings


Press **SETUP** key ▶ Select **Bluetooth** ▶ **Bluetooth connections**. ▶ Select the name of the device to connect. ▶ Connect Bluetooth.



Disconnecting Bluetooth Devices

Disconnects Bluetooth devices that are connected.

Press **SETUP** key ▶ Select **Bluetooth** ▶ **Bluetooth connections**. ▶ Select the name of the device to disconnect.



Deleting Bluetooth Devices

Deletes the Bluetooth devices that you added. Note that deleting a Bluetooth device will delete all Call History and Contact Info downloaded along with it.

Press **SETUP** key ▶ Select **Bluetooth** ▶ **Bluetooth connections** ▶ **Delete devices**.


Select the device name to delete. ▶ Select **Delete**.












Bluetooth Phone

Phone Status Icons


Shows the current phone status in the top right of the display.



Icons	Description
	You can use Bluetooth phones when a Bluetooth Hands-free connection is established.
	You can use Bluetooth audio features when a Bluetooth audio connection is established.
	You can use Bluetooth phones and audio features when both Bluetooth Hands-free and audio connections are established.
	Call signal strength indicator.
	Battery level of the Bluetooth devices connected.
	Downloading Call History list.
	Downloading Contacts.
	In a Bluetooth phone call.
	Microphone muted.

i Information

- The battery level icon and the call signal strength indicator may not be supported in some Bluetooth devices.
- The battery level may differ from the actual level remaining.




Name	Description
1 All	Lists the all call history.
2 Dialled	Lists the calls that you made.
3 Received	Lists the calls that you have received.
4 Missed	Lists the calls you missed.
5 Call History	Displays all of your call history. Select from the list to dial the number.
6 Download	Downloads the call history information from your mobile phone.
7 Bluetooth Settings	Moves to a screen of Bluetooth Settings.

i Information

- In some mobile phones, call records may not be added to your Call History.
- Calls from restricted ID's are not added to your Call History Information.
- Up to 50 calls can be added in each Dialled Calls/Received Calls/Missed Calls list.
- The durations of each dialled/received call are not displayed in your vehicle's Call History list.
- While the call history download is in progress, the status bar displays an icon (📶).
- If the call history download is turned off on the Bluetooth device, the call history download will fail.
- Some devices require a device authentication for downloading your call history. If download fails, check if the Bluetooth settings or display status are normal.
- Some devices do not support call history download. Check if your Bluetooth device supports download feature.

Favourites


Select All Menus ▶ Phone ▶ ☆ .



Name	Description
1 Favourites	Lists the phone numbers saved as Favourites. Select from the list to dial the number.
2 Edit	Add new numbers to Favourites or delete numbers from Favourites.
3 Delete	Deletes numbers that you select from Favourites.
4 Bluetooth Settings	Moves to a screen of Bluetooth Settings.

Contacts

Select All Menus ▶ Phone ▶




Name	Description
1 Contacts List	The list of Contacts. Select from the list to dial the number.
2 Download	Downloads contacts from your mobile phone.
3 Search	Searches Contacts.
4 Bluetooth Settings	Moves to a screen of Bluetooth Settings.



i Information

- Up to 5000 phone numbers can be downloaded from a single, paired Bluetooth device.
 - You cannot edit or delete downloaded phone numbers from your vehicle.
 - Contacts can be viewed only when the Bluetooth device is connected.
 - Even if the Bluetooth device is disconnected, the downloaded data will remain. (note that deleting a paired phone will also delete all downloaded Contacts and Call History data).
 - Downloaded phone numbers may be lost depending on the condition of the Multimedia system. Keep your important data in a safe place.
 - Contacts from both the SIM card and your mobile phone are downloaded at the same time by default.
 - Only supported contacts format can be downloaded and displayed from the Bluetooth device, contacts from some applications will not be included.
- The status bar displays a (📶) while downloading contacts.
 - The download will not be available if the contacts download function is turned off on your Bluetooth device.
 - Some devices require a device authentication for downloading your contacts. If download fails, check your phone screen and confirm the download if necessary.
 - Some devices do not support contacts download feature. Check if your Bluetooth device supports contacts download.

Dial

Select **All Menus** ▶ **Phone** ▶ .




Name	Description
1 Keypad	Use the keypad to enter the phone number that you want to call. Select and hold the last number of a speed dial to dial a number that you added to the Speed Dial list in the phone.
2 Call	Makes a call after you dial a number and select  . If the number is listed in Dialed Calls, you can select the number and select  to automatically dial that number again.
3 Settings	Change the settings for Bluetooth connections.
4 Delete	Deletes the numbers that you entered.
5 Bluetooth Settings	Moves to a screen of Bluetooth Settings.

i Information

- Some types of mobile phones may not support the Speed Dial function.

Accept/Reject Call




If there is an incoming call after you made a Bluetooth connection, a popup message will appear.

Name	Description
1 Accept	Answers the call.
2 Reject	Ignores the call.

i Information

- In some mobile phones, the caller's number may not be displayed, and the Reject feature may not be supported.

Using the Menu During a Phone Call



When making a call, you can use the following menu items.

Name	Description
1 Use private	Switches a voice call from the vehicle Hands-free to the mobile phone.
2 End	Ends a call.
3 Mute	Mutes the microphone during a call.
4 Outgoing Volume	Displays the Mic Volume settings. You can adjust the in-call volume that the other party hears (level 1 to 5).
5 Keypad	Moves to a screen for entering ARS numbers.
6 Switch	Switches to a call on hold, if any. You can also switch calls by selecting the number in the Information Display. The Switch function switches the current call to a waiting call in order to answer a new incoming call.

i Information

- If the caller's number is listed in Contacts, the caller's name will be displayed. Otherwise, only the number will be displayed. In some mobile phones, the phone number may not be displayed.
- In some Bluetooth devices, the Use Private feature may not be supported.
- In some Bluetooth devices, the Switch feature may not be supported.
- Depending on handset types, the in-call volume the other party hears may differ. If the other party hears your voice too low or too loud, adjust the mic volume.

MEMO

part.4 Other Features

Climate

Camera

Using Voice memo

Other Features

Climate

Press the **CLIMATE** key for the climate system to see status information in the full screen display.

When multimedia is in use, the climate system information will be displayed over the top when you control the temperature (TEMP) or turn on the air conditioning (A/C).

Basic Mode Screen



Name	Description
1 Set the temperature of the driver's seat and passenger seats	Displays the configured temperature settings for the driver's seat and the passenger seats. Cooling or heating will continue until the temperature matches the configured temperature settings. i The interior temperature is displayed in units of 0.5 °C.
2 Air direction	Displays the configured air direction settings.
3 Air volume	Displays the configured air volume settings.
4 Cooling/heating control status (AUTO)	Displayed when the AUTO key is pressed and cooling/heating operates automatically according to the configured temperature settings i AUTO will be turned off when you try to do the following with AUTO on: <ul style="list-style-type: none">- Control the air volume- Control the air direction- Turn the air conditioning (A/C) on/off- Turn on the moisture removal function for the windscreen
5 Air conditioning control status	Displayed when the A/C key is pressed and the air conditioning starts cooling/heating.



Name	Description
<p>6 Simultaneous temperature settings for the driver's seat and the passenger seats (SYNC)</p>	<p>Displayed when the SYNC key is pressed and the temperatures of the driver's seat and the passenger seats can be configured at the same time.</p>
<p>7 Outside Temperature</p>	<p>Displays the current temperature outside the vehicle.</p>

Camera

WARNING

- The distance shown in the rear view screen may differ from the actual distance. For safety, be sure to visually check the rear, left, and right sides of your vehicle.
- The colour of the parking guidelines displayed in the picture may differ from the actual screen.
- When booted up, blinking may occur when you switch to a UI screen.

NOTICE

- The rear view screen remains active while you are reversing. When you move the transmission shift lever to any position other than the "R" (Reverse) position after reversing, the rear view screen will be deactivated and the system will display the previous screen automatically.
- As you steer your vehicle, the parking guides change accordingly to indicate your vehicle's path.



- Depending on vehicle models, the steering-interactive parking guides may not be supported.
- If an object comes too close to your vehicle as you are reversing, a warning beep will sound. To prevent an accident that might result if you do not hear the beep, you can set the system to decrease the volume level of any media playing automatically when the vehicle is in reverse. If Reverse warning priority is set in the Sound settings, the audio volume is lowered when your car is driving backward.

Steering-linked camera

When you put the transmission shift lever in the “R” (Reverse) position while the power is on or the engine is running, the system screen will automatically display what is behind you.



Driving direction lines (yellow) **1 2**

These lines show the directions of the vehicle according to the steering angle.

Neutral direction lines (blue) **3**

These lines indicate your vehicle's expected path with the steering wheel in the neutral position. It can help you determine whether the vehicle is in the correct position in a parking space and prevent you from parking too close to the next vehicle.


Crash warning lines (red) **4**





These lines are to prevent a collision.

Using Voice memo

You can record voice memos using the microphone installed in your vehicle and play voice memos on your system.

On the Home screen, touch **All menus** ► **Voice memo**.



Features	Description
1 Display the options list.	<ul style="list-style-type: none"> • Delete: Delete voice memos. • Save to USB: Save voice memos to a USB storage device. <ul style="list-style-type: none"> i This option is available only for USB storage devices formatted in FAT16/32 formats. • Memory: View information on the storage space used for your voice memos.
2 List of your voice memos.	Touch a voice memo to play it.
3 Record/Pause button	<ul style="list-style-type: none"> • Touch  to start recording. • Touch  to pause recording.
4 Stop button	<ul style="list-style-type: none"> • Touch  to stop recording. The recorded memo is added to the voice memos list on the left of the screen. • You can also press the  button on the steering wheel.

i Information

- Voice memo recording mutes the function in operation or pauses media playback.
- If you make or answer a call while recording a voice memo, the recording pauses. If an emergency call is connected, the recording will stop and the recorded voice memo will be saved automatically.

part.5 Settings

Sound settings

Display settings

Bluetooth settings

Phone projection settings

Home screen settings

Date/Time settings

Language settings

Keyboard settings

Screen saver settings

Advanced settings

System info



Settings

Setup is the screen to control Multimedia system settings.

To enter the screen, press **SETUP** key on the steering wheel control or select **Settings** on the All menus screen.

Sound settings

Adjusts the sound effects for the whole system.




Features	Description
1 Position	Select the Up/Down/Left/Right button to control sound positioning. Select centre to concentrate the sound on the centre of vehicle.
2 Volume levels	Adjust the volume levels for various system features, including phone projection.
3 Equaliser	Drag the slide bar to control BASS/MID/TREBLE settings. Select centre to initialise the settings.
4 Loudness	Sets the volume ratio when reversing the vehicle, turning on the vehicle's ignition, etc.
5 Advanced	Select additional audio options such as "Speed dependent volume control" that automatically controls Audio volume according to vehicle speed.
6 Default	Resets the sound to factory default settings.
7 Beep	Select to activate a beep when selecting buttons.

i Information

- Advanced sound settings may differ according to selected AMP option.
- The seat shape may differ according to vehicle model.

Display settings

Adjusts the level of illumination for the entire system.




Features	Description
1 Dimming	Sets the display brightness according to mode changes.
2 Brightness	Use cluster knob enables the system brightness to be adjusted according to the instrument cluster's brightness. If this feature is deactivated, you can adjust the brightness for the day or night mode according to your setting in the Dimming option.
3 Default	Resets the display to factory default settings.
4 Display Off	Provides the Display Off (touch activation) function.

Bluetooth settings


Changes Bluetooth phone settings.

Press **SETUP** key ▶ Select **Bluetooth**.



Bluetooth connection

Press **SETUP** key ▶ Select **Bluetooth** ▶



Features	Description
1 Paired Device List	Displays the paired Bluetooth device list. When selecting from the list, the device is connected or disconnected.
2 Bluetooth Audio Connection Status	An icon appears when you make a Bluetooth Audio connection.
3 Bluetooth Hands-Free Connection Status	An icon appears when you make a Bluetooth Hands-free connection.
4 Add new	Register a new Bluetooth device.
5 Delete devices	Select and delete a paired device.
6 Help	Switches to the Bluetooth Connection Help screen.

i Information


- Up to 5 Bluetooth devices can be paired.
- Only one Bluetooth device can be connected at a time.
- During a Bluetooth device connection, another device cannot be paired.
- When you delete a paired device, the Call History and Contacts stored in the Multimedia system are also deleted.
- Bluetooth Hands-free and Bluetooth Audio functions are supported.
- Hands-free and audio-supported devices, such as a Bluetooth smartphone or audio, will function normally.
- When a Bluetooth device is connected, if the Bluetooth connection is unexpectedly disconnected, due to being out of communication range, the device powering off, or a Bluetooth communication error, the Bluetooth device automatically searches for and connects to nearby Bluetooth devices.
- If the system is not stable, due to a vehicle-Bluetooth device communication error, restore the Default Factory Settings.
- For Default Factory Settings, the Bluetooth settings are reset to factory settings.

Press **SETUP** key ▶ Select **Bluetooth** ▶
Factory settings.

Auto connection priority

Press **SETUP** key ▶ Select **Bluetooth** ▶

Auto connection priority.




When the engine is running, the selected Bluetooth device is automatically connected. If you fail to connect the selected device, the previously-connected device is automatically connected, and if it also fails, then it tries to connect all paired devices sequentially.

Depending on auto connection priority, connection to a device may take time.

System Bluetooth info

Press **SETUP** key ▶ Select **Bluetooth** ▶

System Bluetooth info.



Features	Description
1 Vehicle name	You can change the Bluetooth device name of the vehicle.
2 Passkey	You can change the passkey used for Bluetooth device authentication. The initial passkey is 0000.

i Information

- The vehicle name above is an example. Check the actual information on the product.

Phone projection settings

For more details, refer to the Phone projection guide.

Home screen settings

You can customize the three menu items at the bottom right of the Home Screen into the ones you want.

On the Home Screen Settings screen, drag the menu items on the right to the area marked in red in the screen below.




i Information

- You can select the **Default** button to reset to the factory default settings.

Date/Time settings


Configure the settings for time and date. Using the arrow buttons, you can change the values. Date/Time settings do not automatically change when crossing into different time zones. The time must be changed manually on this screen.



Features	Description
1 24-hour	The time display is set in 24-hour format.
2 Direct entry	If you tap any value, you can directly enter the number in the following screen.
3 Daylight saving time	The daylight saving time (DST) is applied.

Language settings

You can configure the displayed system language.



When the language is changed, the system language is automatically changed. Unique data including MP3 file name is not changed.

Keyboard settings

You can configure the keyboard layout for each language.



i Information

- Configured keyboard layouts are applied to all input modes.

Screen saver settings


You can select any of the following screen formats to be displayed when the screen or power is turned off (press and hold the Power button).

- Digital clock and date
- Analogue clock and date
- None



Advanced settings


Sets alerts per function if desired by the user.



Features	Description
1 Custom button	You can choose the feature to be accessed when the key is pressed.
2 Steering whl mode button	Sets the media to be played when the steering wheel or rear seat (if provided) button is pressed.
3 Media change notifications	Sets whether to display media information at the top of the screen as the next item is played when not on the media screen.

System info

System version information and update details are available.



Features	Description
1 Version info	Select the button to update the system.
2 Memory	View storage information of your system's memory.
3 Default	When is selected, the settings are changed to factory defaults.

System Update

At the System Info screen, insert the USB memory with the latest file downloaded, and then select the button to begin updating. The system will then reboot automatically.

Information

- This product needs supplemented software updates and additional functions, which collectively may take some time to complete, depending on the amount of data.

NOTICE

- If the power is disconnected or the USB is removed during an update, the data might be damaged. Please do not turn off the vehicle while an update is in progress.
- When is selected, it may delete all of the data and settings so be cautious of your action.

part.6 Appendix

Product Specification

Troubleshooting

FAQ

Appendix

Product Specification

TFT-LCD

Screen Size	7 inch (152.4 x 91.44 mm)
Resolution	384,000 pixels (Resolution: 800 x 480)
Operating Method	TFT(Thin Film Transistor) Active Matrix
Viewing Angle	Left/Right, Top/Bottom: ALL 89°
Internal Lighting	LED

Radio

Channels	FM: 87.5 MHz to 108.0 MHz(100 kHz)
	AM: 531 kHz to 1602 kHz(9 kHz)
Sensitivity	FM: Under 10 dBuV/AM: Under 35 dBu EMF
Distortion Factor	Within 2 %

Common

Power Supply	DC 14.4 V	Operating Power	DC 9 V to DC 16 V
Dark Current	1 mA or less		
Operating Temperature	-20 to +70 °C (-4 to +158 °F)	Storage Temperature	-40 to +85 °C (-104 to +185 °F)
Dimensions	221 X 149 X 186.2 mm		
Current Consumption	2.5 A	Weight	1.64 kg

Bluetooth® Wireless Technology

Frequency Range	2400 to 2483.5 MHz	Supported Bluetooth Specification	3.0
Supported Profile	Handsfree(1.6), A2DP(1.2), AVRCP(1.5), PBAP(1.1)		
Aerial power	3 mW (maximum)		
Number of Channels	79 channels		

Troubleshooting

1. Errors which occur during the operation or installation of the device may be mistaken as a malfunction of the actual device.
2. If you are having problems with the device, try the suggestions listed below.
3. If the problems persist, contact your Kia dealer.

Problem	Possible Cause
There are small red, blue, or green dots on the screen	<ul style="list-style-type: none"> • Because the LCD is manufactured with technology requiring high point density, a pixel or lighting deficiency may occur within 0.01% of total pixels
The sound or image is not working	<ul style="list-style-type: none"> • Has the Switch for the vehicle been turned to [ACC] or [ON]? • Has the SYSTEM been turned OFF?
The screen is being displayed but sound is not working	<ul style="list-style-type: none"> • Has the volume been set to a low level? • Has the volume been muted?
When the power is turned on, the corners of the screen are dark	<ul style="list-style-type: none"> • The display appearing somewhat dark after prolonged periods of use is normal with LCD panels. It is not a malfunction • If the screen is very dark, contact your nearest Kia dealer for assistance
Sound is working from only one speaker	<ul style="list-style-type: none"> • Are the positions of Fader or Balance sound controls adjusted to only one side?

Problem	Possible Cause
The external device is not working	<ul style="list-style-type: none"> • Is the external device connected with a standard connector cable?
Upon turning power on, the most recent mode screen is not displayed	<p>Within modes that play files by reading external sources, such as USB, iPod, or Bluetooth streaming mode, the most recently played mode screen prior to turning off power may not properly load.</p> <ul style="list-style-type: none"> • If there is no disc or the corresponding device is not connected, the mode operated prior to the most recent mode will operate • If the previous mode still cannot be properly played, the mode operated prior to that will operate

Problem	Possible Cause	Countermeasure
The power does not turn on	<ul style="list-style-type: none"> The fuse is disconnected 	<ul style="list-style-type: none"> Replace with a suitable fuse If the fuse is disconnected again, please contact your point of purchase or Kia dealer
	<ul style="list-style-type: none"> Device is not properly connected 	<ul style="list-style-type: none"> Check to see that the device has been properly connected
The system does not play	<ul style="list-style-type: none"> The vehicle battery is low 	<ul style="list-style-type: none"> Charge the battery. If the problem persists, contact your point of purchase or Kia dealer.

Problem	Possible Cause	Countermeasure
The image colour/tone quality is low.	<ul style="list-style-type: none"> The brightness, saturation, hue, and contrast levels are not set properly 	<ul style="list-style-type: none"> Properly adjust the brightness, saturation, hue, and contrast levels through Display Setup
Sound does not work	<ul style="list-style-type: none"> The volume level is set to the lowest level A connection has not been made. The device is currently fast-forwarding, rewinding, scanning, or playing in slow mode 	<ul style="list-style-type: none"> Adjust the volume level Check to see that the device has been properly connected The sound will not work when the device is fast-forwarding, rewinding, scanning, or playing in slow mode
	The sound or image quality is low	<ul style="list-style-type: none"> Vibration is occurring from where the conversion switch has been installed Image colour/tone quality is low.

Problem	Possible Cause	Countermeasure
The USB does not work	<ul style="list-style-type: none"> • USB memory is damaged • USB memory has been contaminated 	<ul style="list-style-type: none"> • Please use the USB after formatting it. • Remove any foreign substances on the contact surface of the USB memory and multimedia terminal
	<ul style="list-style-type: none"> • A separately purchased USB HUB is being used • A USB extension cable is being used • A USB which is not a Metal Cover Type USB Memory is being used • An HDD type, CF, SD Memory is being used • There are no music files which can be played 	<ul style="list-style-type: none"> • Directly connect the USB memory with the multimedia terminal on the vehicle • Directly connect the USB memory with the multimedia terminal on the vehicle • Use standard USB Memory • Use standard USB Memory • Only MP3, WMA file formats are supported. Please use only the supported music file formats

Problem	Possible Cause	Countermeasure
The iPod is not recognised even though it has been connected.	<ul style="list-style-type: none"> • There are no titles which can be played • The iPod firmware version has not been properly updated • The iPod device does not recognise downloads. 	<ul style="list-style-type: none"> • Use iTunes to download and save MP3 files into the iPod • Use iTunes to update the firmware version and reconnect the iPod with the device • Reset the iPod and reconnect with the device
Bluetooth does not work or its limited functions are available	<ul style="list-style-type: none"> • Bluetooth on your mobile phone is set to OFF • The Bluetooth connection is not made 	<ul style="list-style-type: none"> • Set it to ON • Make the connection active

i Information

- While operating the device, if an abnormality occurs that cannot be corrected with the above described measures, press the RESET key to reset the system.
- Press and hold the RESET key (over 1 second). The device power will turn off and the system will reset.

FAQ

About Pairing Mobile Phones

Q I cannot pair my mobile phone. What is the cause?

A Check to see that the mobile phone supports Bluetooth function. Verify if Bluetooth on the mobile phone is set to OFF. If so, set it to ON. If the mobile phone still can't be registered, try again after turning Bluetooth off and on, or delete the device registration on the multimedia system and mobile phone and then register the mobile phone again.

Q What is the difference between pairing a mobile phone and connecting a mobile phone?

A Pairing occurs through authenticating the Multimedia system and mobile phone. Mobile phones paired to the Multimedia system can be connected and disconnected until the paired mobile phone is deleted from the system. Bluetooth Handsfree features, such as making/answering calls or managing contacts, are supported only in mobile phones connected with the Multimedia system.

Q What is a Passkey?


A A passkey is the password used to authenticate the connection between the Multimedia system and mobile phone. The passkey only needs to be entered once when pairing the mobile phone for the first time.

The initial passkey is 0000. You can change it with **SETUP** ►

Bluetooth ► **System Bluetooth info** ► **Passkey** menu options.


About Making/Answering Phone Calls

Q How can I answer a call?

A When there is an incoming call, a notification pop-up will become displayed. To answer the incoming call, select **Accept** on the screen or press  key on the steering wheel control.

To reject the call, select **Reject** on the screen or press  key on the steering wheel control.

Q What should I do if I am talking on the Handsfree but want to switch the call to the mobile phone?

A While on a call, press and hold (over 0.8 seconds)  key on the steering wheel control or select **Use Private** at the bottom of the Phone screen to switch the call to your mobile phone.

About *Bluetooth*[®] Wireless Technology/ Multimedia system Use Environment

Q What is the range of my wireless connection?

A The wireless connection can be used within 14 metres.

Q How many mobile phones can be paired?

A It is possible to pair up to five mobile phones.

Q Why is call quality sometimes poor?

A Check the reception sensitivity of the mobile phone when call quality becomes worsened. The call quality may deteriorate when the signal strength is low. Call quality may also worsen if metal objects, such as beverage cans, are placed near the mobile phone. Check to see if there are metal objects in the vicinity of the mobile phone. The call sound and quality may differ depending on the type of mobile phone.

Important Safety Information

Before using your Multimedia system, read and follow all instructions and safety information provided in this end user manual ("User's Guide"). Not following precautions found in this User's Guide can lead to an accident or other serious consequences.

Keep User's Guide in Vehicle

When kept in the vehicle, the User's Guide will be a ready reference for you and other users unfamiliar with the Multimedia system. Please make certain that before using the system for the first time, all persons have access to the User's Guide and read its instructions and safety information carefully.

Warning

Operating certain parts of this system while driving can distract your attention away from the road, and possibly cause an accident or other serious consequences. Do not change system settings or enter data non-verbally (using your hands) while driving. Stop the vehicle in a safe and legal manner before attempting these operations. This is important because removing your hands from the steering wheel while setting up or changing some functions, may distract your attention away from the road.

Prolonged Views of Screen

Do not access any function requiring a prolonged view of the screen while you are driving. Pull over in a safe and legal manner before attempting to access a function of the system requiring prolonged attention. Even occasional short scans to the screen may be hazardous if your attention has been diverted away from your driving task at a critical time.

Volume Setting

Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could cause an accident.

Declaration of conformity

RCM for Australia



MEMO

MEMO