

MODEL NAME	MODEL VARIANT	COF Change Oil & Filter	Intermediate 10K, 30K, 50K, 90 ,70K	Major1 20K, 60K, 100K	Major2 40K	Major2 80K
CADENZA	VG - 3.5L	428	772	1,267	1,816	3,348
CADENZA	YG - 3.3L GDI	476	820	1,281	1,830	4,258
CADENZA	YG - 3.3L MPI	428	772	1,233	1,781	3,313
CARENS	KY - 1.5L GDI	298	611	986	1,317	4,000
CARENS	KY - 1.5L MPI	336	649	1,133	1,464	3,342
CARENS	RP - 1.6L	298	611	1,095	1,426	2,815
CARENS	RP - 2.0L	298	611	1,095	1,426	2,801
CARENS	UN - 2.0L	298	611	999	1,331	2,402
CARNIVAL	KA3.5 - 4L	428	772	1,277	1,825	4,032
CARNIVAL	VQ - 3.8L	474	818	1,216	1,764	3,180
CARNIVAL	YP - 3.3L	428	772	1,294	1,842	3,279
CERATO	BD - 1.6L	336	649	1,172	1,503	3,356
CERATO	BD - 2.0L	336	649	1,172	1,348	2,723
CERATO	TD - 1.6L	298	611	1,274	1,605	2,393
CERATO	TD - 2.0L	298	611	1,274	1,605	2,393
CERATO	YD - 1.6L	298	611	1,354	1,685	2,473
CERATO	YD - 2.0L	298	611	1,014	1,346	2,721

MODEL NAME	MODEL VARIANT	COF Change Oil & Filter	Intermediate 10K, 30K, 50K, 90 ,70K	Major1 20K, 60K, 100K	Major2 40K	Major2 80K
K4000	K4000 - 2.5L	529	842	1,349	2,049	2,142
K4000	K4000 - 2.7L	526	838	1,163	1,863	1,956
K4000	K4000 - 3.0L	483	796	1,167	1,868	1,961
K5	DL3 - 2.0L	298	611	1,081	1,412	3,229
K5	DL3 - 2.5L	428	741	1,211	1,542	3,642
K5	DL3 HEV - 2.0L	428	741	1,233	1,833	3,933
K8	GL3 - 3.5L	428	772	1,277	1,825	3,992
K8	GL3 HEV - 1.6L	382	726	1,270	2,067	3,406
K900	RJ - 3.8L	476	882	1,484	2,125	4,073
K900	RJ - 5.0L	566	972	1,739	2,381	4,925
MOHAVE	HM - 3.8L	428	772	1,166	1,715	3,495
MOHAVE	HM - 4.6L	474	818	1,212	1,761	3,782
NIRO	DE HEV - 1.6L	298	611	1,026	1,626	4,474
OPIRUS	GH - 3.5L	390	796	1,441	2,083	3,749
OPTIMA	JF - 2.0L -CVVL	298	611	1,097	1,428	2,896
OPTIMA	JF - 2.0L GDI	344	657	1,143	1,474	2,942
OPTIMA	JF - 2.0L -MPI	298	611	1,122	1,454	2,829
OPTIMA	JF - 2.4L -MPI	344	657	1,508	1,839	2,627
OPTIMA	MG - 2.7L	344	657	1,088	1,419	2,795
OPTIMA	TF - 2.0L	298	611	1,259	1,590	2,533
PEGAS	AB - 1.4L	303	553	1,204	1,535	2,228

MODEL NAME	MODEL VARIANT	COF	Intermediate	Major1	Major2	Major2
		Change Oil & Filter	10K, 30K, 50K, 90 ,70K	20K, 60K, 100K	40K	80K
PICANTO	JA - 1.2L	303	553	865	1,196	2,499
PICANTO	SA - 1.1L	303	553	1,047	1,378	2,070
PICANTO	TA - 1.2L	303	553	1,173	1,504	2,197
QUORIS	KH - 3.8L	428	834	1,187	1,829	4,164
QUORIS	KH - 5.0L	428	834	1,285	1,926	3,873
RIO	BC - 1.3L	297	547	790	1,121	1,969
RIO	JB - 1.4L	298	549	822	1,153	2,001
RIO	SC - 1.4L	303	553	833	1,164	2,467
RIO	SC - 1.6L	298	549	1,026	1,357	2,205
RIO	UB - 1.4L	298	549	875	1,206	2,500
SELTOS	SP2C - 1.4L GDI	314	627	1,157	1,519	4,300
SELTOS	SP2C - 1.5L	336	649	1,179	1,541	2,942
SELTOS	SP2i - 1.6L	314	627	1,310	1,672	3,061
SONET	QY - 1.5L	336	649	992	1,355	2,998
SORENTO	BL - 3.5L	390	734	971	1,240	2,601
SORENTO	MQ2.2 - 4L (Diesel)	588	900	1,436	3,383	7,614
SORENTO	MQ2.5 - 4L	428	741	1,277	1,825	3,042
SORENTO	MQ3.5 - 4L	428	772	1,277	1,825	4,250
SORENTO	MQ4 HEV - 1.6L	382	726	1,270	2,067	3,406
SORENTO	UM - 2.4L	344	688	1,556	2,105	2,956
SORENTO	UM - 3.3L	428	772	1,301	1,849	3,504
SORENTO	XM - 2.4L	298	642	1,320	1,869	2,657

MODEL NAME	MODEL VARIANT	COF Change Oil & Filter	Intermediate 10K, 30K, 50K, 90 ,70K	Major1 20K, 60K, 100K	Major2 40K	Major2 80K
SOUL	AM - 1.6L	298	611	1,130	1,462	2,309
SOUL	PS - 1.6L	298	611	1,283	1,459	2,402
SOUL	PS - 2.0L	298	611	944	1,275	2,651
SOUL	SK1.6 - 3L	298	611	1,286	1,617	2,405
SPORTAGE	KM - 2.7L	344	657	1,012	1,343	2,705
SPORTAGE	NQ5E - 1.6L	382	695	1,075	1,500	3,976
SPORTAGE	NQ5E - 2.0L	382	695	1,075	1,500	2,872
SPORTAGE	NQ5E - 2.4L	428	741	1,121	1,546	2,918
SPORTAGE	Qle - 1.6L	314	627	998	1,329	2,719
SPORTAGE	Qle - 2.0L	298	611	982	1,593	2,689
SPORTAGE	Qle - 2.4L	344	657	1,028	1,359	2,827
SPORTAGE	SL - 2.0L	298	611	1,150	1,481	2,424
SPORTAGE	SL - 2.4L	298	611	966	1,297	2,424
SPORTAGE	SLE - 2.0L	298	611	966	1,297	2,673
STINGER	CK - 2.0L	390	796	1,270	2,997	4,553
STINGER	CK - 3.3L	428	834	1,457	3,184	5,003
TELLURIDE	ON - 3.8L	476	882	1,408	2,049	4,861

Gasoline Vehicles

COF	Replace: Engine Oil & Oil Filter, Clean: A/C Filter, Air Filter
Intermediate	Replace: Engine Oil & Oil Filter, Clean: A/C Filter, Air Filter, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Brake Fluid, Coolant, Adjust: Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tire Rotation, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges
Major 1	Replace: Engine Oil & Oil Filter, A/C Filter, Air Filter, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Brake Fluid, Coolant, Adjust: Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tire Rotation, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges
Major 2	Replace: Engine Oil & Oil Filter, A/C Filter, Air Filter, Brake Fluid Clean: Electronic Throttle Control, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Coolant, Adjust: Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tire Rotation, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges
Major 2 +	Replace: Engine Oil & Oil Filter, A/C Filter, Air Filter, Brake Fluid, Automatic Transmission Fluid(If applicable), Spark Plugs(If applicable) & Differential Oil (If applicable) Clean: Electronic Throttle Control, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Coolant, Adjust: Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tire Rotation, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges

Hrbrid

COF	Replace: Engine Oil & Oil Filter, Clean: A/C Filter, Air Filter
Intermediate	Replace: Engine Oil & Oil Filter, Clean: A/C Filter, Air Filter, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Brake Fluid, Coolant, Adjust: Tire Rotation Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges
Major 1	Replace: Engine Oil & Oil Filter, A/C Filter, Air Filter, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Brake Fluid, Coolant, Adjust: Tire Rotation Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges
Major 2	Replace: Engine Oil & Oil Filter, A/C Filter, Air Filter, Brake Fluid, HSG belt, Fuel Tank Air Filter, Clean: Electronic Throttle Control, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Coolant, Adjust: Tire Rotation Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges
Major 2 +	Replace: Engine Oil & Oil Filter, A/C Filter, Air Filter, ATF & GEAR OIL(L) Brake Fluid, Spark Plugs(If applicable), Clean: Electronic Throttle Control, Inspect: Vehicle Health Check (VHC), A/C Refrigerant leakage, A/C system Performance, All gauges and Warning Lights, All lights (interior & exterior), All seats & seat belts, Alternator Performance, Horn, Battery Condition, Brake pipes & hoses, Cooling system, hoses, Doors central locks, Drive shaft boots, Engine belts, Exhaust pipes & mounting, Fuel tank cap, fuel lines, Top up: Coolant, Adjust: Tire Rotation Brake Pedal & Parking brake, Tires pressure, Washer fluid, Tighten: Battery terminals, Underneath body bolts, Wheel nut torque as per SDS, Lubricate: Door locks/hinges